

# Power Editor Supporter

## INSTRUCTION MANUAL




September 2024

1st edition

Revision History

No.	Details	Date
1	First edition	06/09/2024

Index .....	3
1. Introduction	
1-1. <a href="#">What is Power Editor R Supporter</a> .....	4
1-2. <a href="#">What is required for operation</a> .....	4
1-3. <a href="#">File description</a> .....	4
2. Preparation	
2-1. <a href="#">Install USB driver</a> .....	5
2-2. <a href="#">Power Editor R connection check</a> .....	6
3. How to use Power Editor R Supporter	
3-1. <a href="#">Starting Power Editor R Supporter</a> .....	7
3-2. <a href="#">Select your vehicle</a> .....	8
3-3. <a href="#">Map selection and rewriting</a> .....	9
3-4. <a href="#">Check after rewriting</a> .....	10



## 1-1. What is Power Editor R Supporter

- Power Editor R Supporter allows you to easily rewrite Power Editor R map data without using Easy Writer.

## 1-2. What is required for operation

- Windows computer. (Windows10 or Windows11.)
  - To start Easy Writer, .Net Framework 4.7.2 or later must be installed on your computer.If it is not installed, you will not be able to start it, so please install it from the Microsoft website.

## 1-3. File description

Name	Date modified	Type	Size
Map Data			
Files	20/08/2024 15:11	File folder	
INSTRUCTION MANUAL			
Manual	19/08/2024 15:14	File folder	
USB driver			
USBDriver	15/08/2024 15:14	File folder	
PER_Supporter.exe	27/02/2024 12:27	Application	1,550 KB
Power Editor R Supporter			

## 2-1. Install USB driver


- Launch CMD212364\_Setup.exe located in the USBDriver folder and follow the displayed steps to proceed with the installation.

Name	Date modified	Type	Size
CDM212364_Setup.exe	12/07/2021 13:11	Application	2,212 KB


Start with double I click




Click "Extract"



Click "Next"



Check "I accept this agreement" and click "Next"



Click "Finish"

## 2-2. Power Editor R connection check

- Remove the waterproof connector inserted into the vehicle-specific harness of Power Editor R, and connect the included USB harness.

Remove the waterproof connector.



Connect the USB harness.



- After you finish using Easy Writer, remove the USB harness and Please reinstall the waterproof connector.


- Connect Power Editor R to your computer via USB.
- Open the Device Manager on Windows OS and if [USB Serial Port] is displayed under ports (COM and LPT), Power Editor R is connected correctly.

[How to open device manager]

Right-click the Windows Start button and select "Device Manager".


- If a serial device other than Power Editor R is connected to your computer, multiple [USB Serial Port] may be displayed.

In that case, please unplug the Power Editor R's USB and then plug it back in to make sure that the Power Editor R is recognized.




## 3-1. Starting Power Editor R Supporter

- Run PER\_Supporter.exe.






Double-click to launch.

If the Power Editor R unit is not connected, the current status will not be displayed.



## 3-2. Select your vehicle

- Please select the vehicle model from the pull-down menu according to the vehicle in which you will be installing Power Editor R.




- The number of selectable maps varies depending on the vehicle model or map concept.



## 3-3. Map selection and rewriting

- Select a map and press the Map Rewrite button to start rewriting.



## 3-4. Check after rewriting

- You can check the map name to confirm that it has been correctly rewritten to the selected map.

- For map version "AT020-01.3", "AT020-01" is the base map name and the ".3" at the end is the number of the selected map.

- The status will be automatically updated once the rewrite is complete, but you can also update the status by clicking "Current Status".

Status update button.

Check the map name.



